



# ASUS UX50V-RX05 Case Removal

Prerequisite Only

Written By: James






## TOOLS:

- [iFixit Opening Tools](#) (1)
  - [Spudger](#) (1)
  - [Pro Tech Toolkit](#) (1)
-


## Step 1 — Keyboard



⚠ Make sure the device is powered off before beginning.

- Use the Plastic Opening tool to pry the five slots up at the top of the keyboard.


## Step 2



- Lift the keyboard slowly but not all of the way out.
- Use the Plastic Opening tool to open the two black clips on each side of the connecting cords, (LCD flex cable and flex band).
- After pushing each end of the clips out, towards the entering cable, you can then pull out the cable.




## Step 3




- Push out each end of the black clip with a plastic opening tool or nylon spudger to remove the ribbon cable.

## Step 4 — Case Removal



- Remove the 13 Phillips 4mm head size 5 mm long screws from the back of the laptop.
- Once the keyboard has been removed, use the spudger tool to pry around the edge of the laptop until it frees.

## Step 5



- Use the spudger tool to unplug the two cords from the body by pushing on the tabs on the side of each plug towards the cable.

## Step 6



- Now that those two cords are unplugged, you can work on unplugging the black cord.
- Use either your fingers to pull up on the clear tab, or the spudger tool by pushing the two sides out, like the step before.

## Step 7



- Now slowly lift the plastic cover as to not accidentally damage something.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-25 09:18:23 AM.